



CONTROL STATION

MACHINE TYPE 1

MACHINE TYPE 2

MACHINE TYPE 3

MACHINE TYPE 4

AUTO UPGRADE

AUTO X UPGRADE

MULTI UPGRADE

teleop

A ONE TO ONE SYSTEM. ONE CONTROL STATION OPERATES ONE MACHINE. IT CAN BE ANY TYPE OF MACHINE (rockbreaker, lhd, drill, etc.)



teleop

AUTO


A ONE TO ONE SYSTEM. ONE CONTROL STATION OPERATES ONE DRIVING MACHINE (lhd, truck, etc.). WITH THE AUTO UPGRADE, THE MACHINE HAS AUTO SPEED, STEERING, BRAKING.



teleop

MULTI

THE MULTI UPGRADE ALLOWS NUMEROUS MACHINES (ANY TYPE) TO BE ACCESSED ONE AT A TIME FROM THE CONTROL STATION. ONLY ONE MACHINE CAN BE OPERATED AT A TIME.



teleop

AUTO X

THE AUTOX UPGRADE ALLOWS NUMEROUS MACHINES (ANY TYPE) TO BE ACCESSED ONE AT A TIME FROM THE CONTROL STATION. MULTIPLE MACHINES CAN BE OPERATED SIMULTANEOUSLY. DRIVING MACHINES HAVE AUTO SPEED, STEERING AND BRAKING.

